



TV-C202S

PH

SERVICE MANUAL

COLOR TELEVISION

- Replace this Service manual with "Revision Publishing" when it is issued.

aiwa

S/M Code No. 09-00B-421-9T2

SIMPLE

DATA

PARTS LIST

! =  SAFTY PARTS
C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	ACC		86-LB4-951-010	2M	RC UNIT,RC-6VT06	PHJ3K1C	TV-C202S
X	ACC		87-B30-274-010	0E	BAT,R6P ATC	PHJ3K1C	TV-C202S
O	ACC		8Z-JB6-610-010	1E	ANT ASSY,TV 5 SEC (PAL)PT CROW	PHJ3K1C	TV-C202S
O	APPEAR		86-LB4-005-010	0E	LENS,RC	PHJ3K1C	TV-C202S
O	APPEAR		86-LB4-012-110	2	CABI,REAR KE	PHJ3K1C	TV-C202S
X	APPEAR		86-LB4-032-010	2P	CABI,FR C202S M	PHJ3K1C	TV-C202S
X	APPEAR		86-LB4-033-010	1	PANEL,FR C202S M	PHJ3K1C	TV-C202S
X	APPEAR		86-LBR-004-010	0E	LENS,LED	PHJ3K1C	TV-C202S
X	APPEAR		86-LBR-020-010	0E	PLATE,FBT S	PHJ3K1C	TV-C202S
!	O APPEAR		87-054-086-010	1A	BADGE,AIWA 52.5 ABS GLD	PHJ3K1C	TV-C202S
O	APPEAR		8Z-JBW-007-010	0E	PLATE,FOOT ST	PHJ3K1C	TV-C202S
O	AUDIO	C 0361	87-A12-087-080	0E	CAP,E 1-50 SMG	PHJ3K1C	TV-C202S
O	AUDIO	C 0381	87-A12-091-080	0E	CAP,E 10-50 SMG	PHJ3K1C	TV-C202S
O	AUDIO	C 0382	87-A12-091-080	0E	CAP,E 10-50 SMG	PHJ3K1C	TV-C202S
O	AUDIO	C 0401	87-A12-068-090	0E	CAP,E 470-16 SMG	PHJ3K1C	TV-C202S
O	AUDIO	C 0402	87-A12-086-080	0E	CAP,E 0.47-50 SMG	PHJ3K1C	TV-C202S
O	AUDIO	C 0403	87-A10-831-090	1A	CAP,E 1000-25 M SMG	PHJ3K1C	TV-C202S
O	AUDIO	C 0404	87-A12-072-080	0E	CAP,E 100-25 SMG	PHJ3K1C	TV-C202S
O	AUDIO	C 0405	87-A12-090-080	0E	CAP,E 4.7-50 SMG	PHJ3K1C	TV-C202S
O	AUDIO	C 0406	87-A10-210-010	0E	CAP,CER 0.047-50 M	PHJ3K1C	TV-C202S
O	AUDIO	C 0407	87-A11-148-080	0E	CAP,TC U 0.1-50 Z F	PHJ3K1C	TV-C202S
O	AUDIO	C 0408	87-A10-730-080	0E	CAP,E 1000-16 SMG	PHJ3K1C	TV-C202S
X	AUDIO	C 0419	88-700-719-810	0E	CAP,M 3900P-50 J	PHJ3K1C	TV-C202S
O	AUDIO	C 0429	87-A12-091-080	0E	CAP,E 10-50 SMG	PHJ3K1C	TV-C202S
O	AUDIO	C 0431	87-A12-087-080	0E	CAP,E 1-50 SMG	PHJ3K1C	TV-C202S
O	AUDIO	CN 0401	86-LBR-690-210	1A	CONN ASSY,2P SPMONO	PHJ3K1C	TV-C202S
O	AUDIO	CN 0402	86-LB4-692-210	1A	CONN ASSY,2P SP RIGHT	PHJ3K1C	TV-C202S
S	AUDIO	IC 0401	87-070-117-010	1C	IC,AN5265	PHJ3K1C	TV-C202S
O	AUDIO	J 0401	87-A60-680-010	1A	JACK,PIN 4P Y-BLK HTJ-036-22	PHJ3K1C	TV-C202S
O	AUDIO	J 0402	87-A60-329-110	0E	JACK,3.5 BLK MONO W/SW	PHJ3K1C	TV-C202S
O	AUDIO	J 0403	87-A60-370-010	1A	JACK,PIN 2P BLK-Y W/SW	PHJ3K1C	TV-C202S
S	AUDIO	Q 0303	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	AUDIO	Q 0308	87-A30-121-080	0E	TR,DTC323TS	PHJ3K1C	TV-C202S
S	AUDIO	Q 0313	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	AUDIO	Q 0321	87-A30-121-080	0E	TR,DTC323TS	PHJ3K1C	TV-C202S
S	AUDIO	Q 0403	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
X	AUDIO	R 0357	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0362	88-121-104-080	0E	RES,100K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0364	88-121-104-080	0E	RES,100K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0383	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0391	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0401	88-130-100-080	0E	RES,10-1/4W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0403	88-121-472-080	0E	RES,4.7K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0404	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0411	88-121-561-080	0E	RES,560-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0412	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0413	88-121-563-080	0E	RES,56K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0414	88-121-104-080	0E	RES,100K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0415	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0417	88-121-563-080	0E	RES,56K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0418	88-121-104-080	0E	RES,100K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0419	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0420	88-121-681-080	0E	RES,680-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0421	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	AUDIO	R 0422	88-140-479-080	0E	RES,4.7-1/2W J	PHJ3K1C	TV-C202S
O	AUDIO	R 0423	87-025-569-010	0E	RES,M/F 47-1/2W J	PHJ3K1C	TV-C202S
O	AUDIO	R 0436	87-A00-284-090	0E	RES,FUSE 8.2-2W J R-TYPE	PHJ3K1C	TV-C202S
!	O CRT	V 0551	86-LB4-610-010	3P	CRT,A48KRD89X01	PHJ3K1C	TV-C202S
O	DEFLECTION		87-067-579-010	0E	BVT2+3-8 W/O SL0T	PHJ3K1C	TV-C202S
O	DEFLECTION	BT 0301	86-LB7-691-010	1A	CONN ASSY,5P TN-3	PHJ3K1C	TV-C202S
O	DEFLECTION	BT 0801	84-LB3-690-110	1	CONN ASSY,4P TN-1	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0501	87-018-127-080	0E	CAP,TC U 470P-50 K B UP050	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0502	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0503	87-A12-087-080	0E	CAP,E 1-50 SMG	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0506	87-A10-408-080	0E	CAP,CER 560P-500 K YP	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0507	87-012-357-010	0E	CAP,CER 47P-500 J CH DD10	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0508	87-018-131-080	0E	CAP,TC U 1000P-50 K B UP050	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0509	87-A12-095-080	0E	CAP,E 100-50 SMG	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0510	87-A12-080-080	0E	CAP,E 220-35 SMG	PHJ3K1C	TV-C202S
X	DEFLECTION	C 0511	88-707-789-810	0E	CAP,M 0.33-50 J TF ECQ	PHJ3K1C	TV-C202S

PARTS LIST

! =  SAFTY PARTS
C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	DEFLECTION	C 0512	88-707-789-810	0E	CAP,M 0.33-50 J TF ECQ	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0513	87-A10-831-090	1A	CAP,E 1000-25 M SMG	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0514	87-A12-087-080	0E	CAP,E 1-50 SMG	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0603	87-A12-492-080	0E	CAP,CER 1000P-500 K B Y5P	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0605	87-016-481-010	1A	CAP,M/P 0.47-200 J DHS	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0606	87-016-357-010	1B	CAP,M/P 0.01-1.25K PH	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0607	87-A10-860-090	0E	CAP,CER 470P-2K K R	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0609	87-010-709-080	0E	CAP,E 0.22-50 M BP SM	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0610	88-238-450-810	0E	CAP,CER 150P-500 K YP	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0620	87-016-220-090	1A	CAP,E 47-160 M TWSS	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0830	87-012-386-080	0E	CAP,CER 470P-2K K BN DE	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0831	87-016-373-080	1A	CAP,E 10-250 M SME	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0832	87-010-397-090	1A	CAP,E 1000-35 M SME	PHJ3K1C	TV-C202S
O	DEFLECTION	C 0833	87-A12-492-080	0E	CAP,CER 1000P-500 K B Y5P	PHJ3K1C	TV-C202S
O	DEFLECTION	CN 0601	87-099-675-010	1A	CONN,5P V V	PHJ3K1C	TV-C202S
S	DEFLECTION	D 0501	87-070-274-080	0E	DIODE,1N4003 SEM	PHJ3K1C	TV-C202S
S	DEFLECTION	D 0603	87-A40-291-080	0E	DIODE,1N4148M (CPT)	PHJ3K1C	TV-C202S
S	DEFLECTION	D 0815	87-A40-286-080	0E	DIODE,RGP10JE-5025	PHJ3K1C	TV-C202S
S	DEFLECTION	D 0816	87-A40-286-080	0E	DIODE,RGP10JE-5025	PHJ3K1C	TV-C202S
S	DEFLECTION	D 0820	87-A40-286-080	0E	DIODE,RGP10JE-5025	PHJ3K1C	TV-C202S
O	DEFLECTION	FB 0601	87-003-223-080	0E	F-BEAD, BL02RN2	PHJ3K1C	TV-C202S
X	DEFLECTION	HT 0501	8Z-JBR-213-010	0E	HT-SINK,V-DR	PHJ3K1C	TV-C202S
X	DEFLECTION	HT 0602	8Z-JBR-212-010	0E	HT-SINK,C	PHJ3K1C	TV-C202S
S	DEFLECTION	IC 0501	87-070-237-010	1C	IC,LA7832	PHJ3K1C	TV-C202S
O	DEFLECTION	L 0601	88-JBJ-625-010	1B	COIL,HLC-ELH5L4120N	PHJ3K1C	TV-C202S
S	DEFLECTION	Q 0501	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	DEFLECTION	Q 0601	89-334-674-580	1A	TR,2SC3467 (D/E)	PHJ3K1C	TV-C202S
S	DEFLECTION	Q 0602	87-A30-095-010	1E	TR,2SD2333	PHJ3K1C	TV-C202S
S	DEFLECTION	Q 0603	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0502	88-121-472-080	0E	RES,4.7K-1/8W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0503	88-121-332-080	0E	RES,3.3K-1/8W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0504	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0506	88-121-183-080	0E	RES,18K-1/8W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0507	88-121-154-080	0E	RES,150K-1/8W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0509	88-121-333-080	0E	RES,33K-1/8W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0510	88-140-102-080	0E	RES,1K-1/2W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0512	88-121-681-080	0E	RES,680-1/8W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0513	88-140-109-080	0E	RES,1-1/2W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0517	88-121-393-080	0E	RES,39K-1/8W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0518	88-140-681-080	0E	RES,680-1/2W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0602	88-121-152-080	0E	RES,1.5K-1/8W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0603	88-121-222-080	0E	RES,2.2K-1/8W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0604	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0605	88-140-222-080	0E	RES,2.2K-1/2W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0606	88-121-471-080	0E	RES,470-1/8W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0607	88-121-101-080	0E	RES,100-1/8W J	PHJ3K1C	TV-C202S
O	DEFLECTION	R 0608	87-A00-185-010	1A	RES,CEM 2.2K-5W J ZY	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0609	88-140-472-080	0E	RES,4.7K-1/2W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0614	88-121-104-080	0E	RES,100K-1/8W J	PHJ3K1C	TV-C202S
X	DEFLECTION	R 0615	88-121-333-080	0E	RES,33K-1/8W J	PHJ3K1C	TV-C202S
O	DEFLECTION	R 0616	87-A00-049-060	0E	RES,FUSE 2.2K-1/2W J R-TYPE	PHJ3K1C	TV-C202S
O	DEFLECTION	R 0818	87-A00-419-090	1D	RES,FUSE 1-2W J ERQ2Z	PHJ3K1C	TV-C202S
O	DEFLECTION	R 0821	87-A00-052-060	0E	RES,FUSE 3.9-1W J R-TYPE	PHJ3K1C	TV-C202S
O	DEFLECTION	SW 0501	87-A90-567-010	1A	SW,LVR 4-1-3 EVQRAAL10	PHJ3K1C	TV-C202S
!	O DEFLECTION	T 0601	84-LB3-651-010	1B	TRANS,HD MS-101N	PHJ3K1C	TV-C202S
!	O DEFLECTION	T 0602	88-JBJ-607-010	2M	FBT, HFT3601B	PHJ3K1C	TV-C202S
O	KNOB		86-LB4-035-010	0E	BTN,POWER ST M	PHJ3K1C	TV-C202S
X	LBL, POP		86-LB4-971-010	-	LBL,POP PHJ	PHJ3K1C	TV-C202S
X	LBL, POP		87-JB8-972-010	0E	LBL,POP NO.1	PHJ3K1C	TV-C202S
O	NK	C 0551	87-A12-492-080	0E	CAP,CER 1000P-500 K B Y5P	PHJ3K1C	TV-C202S
O	NK	C 0552	87-016-037-060	0E	CAP,CER 1000P-2K K B DE	PHJ3K1C	TV-C202S
O	NK	C 0553	87-018-125-080	0E	CAP,TC U 330P-50 K B UP050	PHJ3K1C	TV-C202S
O	NK	C 0554	87-018-126-080	0E	CAP,TC U 390P-50 K B UP050	PHJ3K1C	TV-C202S
O	NK	C 0555	87-018-129-080	0E	CAP,TC U 680P-50 K B UP050	PHJ3K1C	TV-C202S
O	NK	C 0557	87-A12-091-080	0E	CAP,E 10-50 SMG	PHJ3K1C	TV-C202S
!	O NK	CN 0551	87-049-469-010	0E	CONN,4P V WHT EH	PHJ3K1C	TV-C202S
!	O NK	CN 0552	87-009-033-010	0E	CONN,5P V WHT PH	PHJ3K1C	TV-C202S
O	NK	CN 0553	87-099-672-010	0E	CONN,1P V LV GRA	PHJ3K1C	TV-C202S
O	NK	L 0551	87-005-614-080	0E	COIL,100UH J LAV35	PHJ3K1C	TV-C202S
S	NK	Q 0551	89-342-174-510	1A	TR,2SC4217 (D/E)	PHJ3K1C	TV-C202S

PARTS LIST

! = Δ SAFTY PARTS
C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
S NK		Q 0552	89-342-174-510	1A	TR,2SC4217 (D/E)	PHJ3K1C	TV-C202S
S NK		Q 0553	89-342-174-510	1A	TR,2SC4217 (D/E)	PHJ3K1C	TV-C202S
S NK		Q 0554	87-A30-066-080	0E	TR,2SA1175FE	PHJ3K1C	TV-C202S
O NK		R 0551	87-A00-041-060	0E	RES,M/F 12K-2W J L-FORMING	PHJ3K1C	TV-C202S
O NK		R 0552	87-A00-041-060	0E	RES,M/F 12K-2W J L-FORMING	PHJ3K1C	TV-C202S
O NK		R 0553	87-A00-041-060	0E	RES,M/F 12K-2W J L-FORMING	PHJ3K1C	TV-C202S
X NK		R 0554	88-140-332-080	0E	RES,3.3K-1/2W J	PHJ3K1C	TV-C202S
X NK		R 0555	88-140-332-080	0E	RES,3.3K-1/2W J	PHJ3K1C	TV-C202S
X NK		R 0556	88-140-332-080	0E	RES,3.3K-1/2W J	PHJ3K1C	TV-C202S
X NK		R 0557	88-121-152-080	0E	RES,1.5K-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0559	88-121-221-080	0E	RES,220-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0560	88-121-152-080	0E	RES,1.5K-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0562	88-121-182-080	0E	RES,1.8K-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0563	88-121-221-080	0E	RES,220-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0564	88-121-152-080	0E	RES,1.5K-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0565	88-121-182-080	0E	RES,1.8K-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0566	88-121-221-080	0E	RES,220-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0567	88-121-151-080	0E	RES,150-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0568	88-121-391-080	0E	RES,390-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0569	88-121-151-080	0E	RES,150-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0570	88-121-182-080	0E	RES,1.8K-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0571	88-121-331-080	0E	RES,330-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0572	88-121-331-080	0E	RES,330-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0573	88-121-561-080	0E	RES,560-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0574	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0575	88-121-332-080	0E	RES,3.3K-1/8W J	PHJ3K1C	TV-C202S
X NK		R 0576	88-121-821-080	0E	RES,820-1/8W J	PHJ3K1C	TV-C202S
O NK		SFR0551	87-024-522-080	0E	SFR,4.7K V RH063LC	PHJ3K1C	TV-C202S
O NK		SFR0552	87-024-522-080	0E	SFR,4.7K V RH063LC	PHJ3K1C	TV-C202S
O NK		SFR0553	87-024-522-080	0E	SFR,4.7K V RH063LC	PHJ3K1C	TV-C202S
O NK		SFR0554	87-024-519-080	0E	SFR,470 V RH063LC	PHJ3K1C	TV-C202S
O NK		SFR0555	87-024-519-080	0E	SFR,470 V RH063LC	PHJ3K1C	TV-C202S
O NK		SO 0551	86-LBR-670-010	1B	SOCKET,CRT 9P HPS1521	PHJ3K1C	TV-C202S
X NK		TP 0552	87-033-144-010	0E	PIN,DIA1 LONG	PHJ3K1C	TV-C202S
X OTHER			80-MQ1-209-010	0E	CLOTH,20-7	PHJ3K1C	TV-C202S
X OTHER			81-JT1-233-010	0E	CLOTH,5-10-0.5	PHJ3K1C	TV-C202S
O OTHER			84-LB3-205-010	0E	SPR-E,EARTH	PHJ3K1C	TV-C202S
X OTHER			86-LB2-202-010	0E	CLOTH,15-440-0.5	PHJ3K1C	TV-C202S
O OTHER			86-LB7-212-010	1A	HLD,FBT	PHJ3K1C	TV-C202S
! X OTHER			86-LBP-201-110	1A	CUSH-R, 15-15-8	PHJ3K1C	TV-C202S
X OTHER			86-LBR-203-010	0E	SH, PVC 15-20-0.5	PHJ3K1C	TV-C202S
X OTHER			86-LBR-204-010	0E	TAPE,100-19	PHJ3K1C	TV-C202S
X OTHER			86-LBR-205-010	0E	CLOTH,15-95-0.5	PHJ3K1C	TV-C202S
X OTHER			86-LBR-206-010	0E	CLOTH,10-75-0.5	PHJ3K1C	TV-C202S
O OTHER			86-LBU-201-010	0E	HLD,AC CORD	PHJ3K1C	TV-C202S
! X OTHER			87-069-033-010	0E	CABLE,TIE	PHJ3K1C	TV-C202S
O OTHERS,E			84-LB2-633-210	1E	CONN ASSY,1P CRT GND	PHJ3K1C	TV-C202S
O OTHERS,E			84-LB3-641-010	2A	SPKR,F DIA77 8OHM 2W	PHJ3K1C	TV-C202S
! O OTHERS,E			86-LB7-694-010	1H	AC CORD SET,KE2 BLK	PHJ3K1C	TV-C202S
! S OTHERS,E			87-035-458-010	0E	FUSE,4A 250V T 218	PHJ3K1C	TV-C202S
! O OTHERS,E			87-A90-332-010	0E	HLD, SF-2001 HV CABLE	PHJ3K1C	TV-C202S
! O OTHERS,E			87-JBD-625-010	1H	DGC,20 15 OHM	PHJ3K1C	TV-C202S
X PACKING			81-ZG1-855-010	0E	BAG,PV ANTI	PHJ3K1C	TV-C202S
X PACKING			84-LB2-857-010	1F	BAG,FOAMED MAT	PHJ3K1C	TV-C202S
X PACKING			86-LB4-551-010	-	CUSHION,SUB M	PHJ3K1C	TV-C202S
X PACKING			86-LB4-552-010	-	PAD,SHEET SP	PHJ3K1C	TV-C202S
X PACKING			86-LB4-870-010	-	CUSHION,BOTTOM C	PHJ3K1C	TV-C202S
X PACKING			86-LB4-871-010	-	CUSHION, TOP C	PHJ3K1C	TV-C202S
X PACKING			86-LB4-872-010	-	CTN, OUTER CRT	PHJ3K1C	TV-C202S
X PACKING			86-LB4-873-010	-	CUSHION, CRT C	PHJ3K1C	TV-C202S
X PACKING			86-LB4-875-010	-	SH,PV 0.05-800-1300	PHJ3K1C	TV-C202S
X PACKING			86-LB4-876-010	-	CTN, OUTER MAIN	PHJ3K1C	TV-C202S
X PACKING			86-LB4-877-010	-	CUSHION, BOTTOM C	PHJ3K1C	TV-C202S
X PACKING			86-LB4-878-010	-	CUSHION, TOP C	PHJ3K1C	TV-C202S
X PACKING			86-LB4-884-010	-	CTN, OUTER SP	PHJ3K1C	TV-C202S
X PACKING			86-LB4-885-010	-	BD, ASSY SP	PHJ3K1C	TV-C202S
X PACKING			86-LB4-886-010	-	BD, SECTION C	PHJ3K1C	TV-C202S
X PACKING			86-LB4-887-010	-	BD, SECTION D	PHJ3K1C	TV-C202S
X PACKING			86-LB4-889-010	-	BD, PAD SP	PHJ3K1C	TV-C202S
X PACKING			86-LB4-890-010	-	CTN, INNER SCREW	PHJ3K1C	TV-C202S

PARTS LIST

! =  SAFTY PARTS
C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME	
X	PACKING		86-LB4-890-010	-	CTN, INNER SCREW	PHJ3K1C	TV-C202S	
X	PACKING		86-LB4-890-010	-	CTN, INNER SCREW	PHJ3K1C	TV-C202S	
X	PACKING		86-LB4-890-010	-	CTN, INNER SCREW	PHJ3K1C	TV-C202S	
X	PACKING		86-LB4-890-010	-	CTN, INNER SCREW	PHJ3K1C	TV-C202S	
X	PACKING		86-LB4-892-010	-	CUSHION, PAD SP	PHJ3K1C	TV-C202S	
X	PACKING		86-LB4-893-010	-	CTN, OUTER ACCESSORY	PHJ3K1C	TV-C202S	
X	PACKING		86-LB4-894-010	-	CTN, OUTER SCREW	PHJ3K1C	TV-C202S	
X	PACKING		86-LB4-894-010	-	CTN, OUTER SCREW	PHJ3K1C	TV-C202S	
X	PACKING		86-LB4-894-010	-	CTN, OUTER SCREW	PHJ3K1C	TV-C202S	
X	PACKING		86-LB4-897-010	-	CTN, OUTER SCREW/3M	PHJ3K1C	TV-C202S	
X	PACKING		86-LB4-898-010	-	SH, BUBB-MAT 4-130-250	PHJ3K1C	TV-C202S	
X	PACKING		86-LB4-899-010	-	CTN, PRINTED PHJ3K1C	PHJ3K1C	TV-C202S	
X	PACKING		87-066-133-010	0E	BAG, PV 0.04-75-280	PHJ3K1C	TV-C202S	
X	PLATE		86-LB4-039-010	-	LBL, CAUTION AC CORD C	PHJ3K1C	TV-C202S	
X	PLATE		86-LB4-040-010	-	LBL, SPEC C202S PH	PHJ3K1C	TV-C202S	
X	PLATE		87-056-081-010	0E	LBL, SERIAL NO	PHJ3K1C	TV-C202S	
X	PLATE		87-B40-281-010	0E	LBL, BAR-CODE A 35X8	PHJ3K1C	TV-C202S	
O	POWER		87-067-584-010	0E	BVT2+3-6 W/O SLOt	PHJ3K1C	TV-C202S	
O	POWER		87-067-680-010	0E	BVIT3B+3-10	PHJ3K1C	TV-C202S	
O	POWER		87-A90-667-010	0E	COVER, CAP 851640-23	PHJ3K1C	TV-C202S	
!	O POWER	C	0801	87-A10-688-090	1A	CAP, M/P 0.22-275 K (B81133)	PHJ3K1C	TV-C202S
!	O POWER	C	0802	87-A10-688-090	1A	CAP, M/P 0.22-275 K (B81133)	PHJ3K1C	TV-C202S
O	POWER	C	0806	88-238-630-810	0E	CAP, CER 1500P-500 K YP	PHJ3K1C	TV-C202S
O	POWER	C	0807	87-A12-091-080	0E	CAP, E 10-50 SMG	PHJ3K1C	TV-C202S
O	POWER	C	0809	87-016-515-080	0E	CAP, CER 1000P-1K K B DE	PHJ3K1C	TV-C202S
O	POWER	C	0810	87-A10-647-090	1E	CAP, E 220-400 SMH	PHJ3K1C	TV-C202S
O	POWER	C	0811	87-A12-067-080	0E	CAP, E 330-16 SMG	PHJ3K1C	TV-C202S
!	O POWER	C	0812	87-A10-519-010	1A	CAP, CER 4700P-4K M E KX	PHJ3K1C	TV-C202S
O	POWER	C	0813	87-A12-493-080	0E	CAP, CER 2200P-500 K B Y5P	PHJ3K1C	TV-C202S
O	POWER	C	0814	87-A10-238-010	1A	CAP, M/P 1000P-1.6K J DKR	PHJ3K1C	TV-C202S
O	POWER	C	0818	87-A12-058-080	0E	CAP, E 470-6.3 SMG	PHJ3K1C	TV-C202S
O	POWER	C	0820	87-A12-492-080	0E	CAP, CER 1000P-500 K B Y5P	PHJ3K1C	TV-C202S
O	POWER	C	0821	87-010-389-090	1A	CAP, E 2200-25 M SME	PHJ3K1C	TV-C202S
O	POWER	C	0825	87-010-389-090	1A	CAP, E 2200-25 M SME	PHJ3K1C	TV-C202S
O	POWER	C	0835	87-A12-073-080	0E	CAP, E 220-25 SMG	PHJ3K1C	TV-C202S
O	POWER	C	0837	87-A12-091-080	0E	CAP, E 10-50 SMG	PHJ3K1C	TV-C202S
O	POWER	C	0838	87-A10-832-010	0E	CAP, CER 1000P-1K K R LONG	PHJ3K1C	TV-C202S
O	POWER	C	0839	87-A10-730-080	0E	CAP, E 1000-16 SMG	PHJ3K1C	TV-C202S
O	POWER	C	0840	87-A10-731-090	1C	CAP, E 220-160 M KMF	PHJ3K1C	TV-C202S
!	O POWER	CN	0801	82-481-649-010	0E	CONN, 2P V VT-50P	PHJ3K1C	TV-C202S
!	O POWER	CN	0802	87-099-674-010	0E	CONN, 2P V VA	PHJ3K1C	TV-C202S
S	POWER	D	0801	87-A40-371-010	1B	DIODE, D3SBA60-4101	PHJ3K1C	TV-C202S
S	POWER	D	0805	87-A40-286-080	0E	DIODE, RGP10JE-5025	PHJ3K1C	TV-C202S
S	POWER	D	0806	87-A40-286-080	0E	DIODE, RGP10JE-5025	PHJ3K1C	TV-C202S
S	POWER	D	0807	87-A40-286-080	0E	DIODE, RGP10JE-5025	PHJ3K1C	TV-C202S
S	POWER	D	0808	87-A40-286-080	0E	DIODE, RGP10JE-5025	PHJ3K1C	TV-C202S
S	POWER	D	0809	87-A40-757-080	0E	ZENER, UZ7.5BSC	PHJ3K1C	TV-C202S
S	POWER	D	0810	87-070-111-060	1B	DIODE, RU30A	PHJ3K1C	TV-C202S
S	POWER	D	0812	87-017-354-080	1A	DIODE, RU3	PHJ3K1C	TV-C202S
S	POWER	D	0813	87-017-354-080	1A	DIODE, RU3	PHJ3K1C	TV-C202S
O	POWER	FB	0802	87-003-223-080	0E	F-BEAD, BL02RN2	PHJ3K1C	TV-C202S
O	POWER	FB	0803	87-003-223-080	0E	F-BEAD, BL02RN2	PHJ3K1C	TV-C202S
O	POWER	FC	0801	87-033-213-080	0E	FUSE CLAMP, PFC5000	PHJ3K1C	TV-C202S
O	POWER	FC	0802	87-033-213-080	0E	FUSE CLAMP, PFC5000	PHJ3K1C	TV-C202S
X	POWER	HT	0801	87-A90-073-010	1A	HT-SINK, OSH1743	PHJ3K1C	TV-C202S
X	POWER	HT	0805	87-038-099-010	0E	HT-SINK, 20DG/W(FE)	PHJ3K1C	TV-C202S
S	POWER	IC	0801	87-A20-517-010	2A	IC, STR-S6707	PHJ3K1C	TV-C202S
!	O POWER	IC	0802	87-A30-096-010	1A	P-COUPLER, TLP721F	PHJ3K1C	TV-C202S
S	POWER	IC	0803	87-A30-041-110	1C	TR, SE115N	PHJ3K1C	TV-C202S
S	POWER	IC	0804	87-A21-785-010	1A	IC, KIA7812API	PHJ3K1C	TV-C202S
S	POWER	IC	0805	87-A21-788-010	1A	IC, KIA7809API	PHJ3K1C	TV-C202S
S	POWER	IC	0806	87-020-881-080	1A	IC, NJM78L05A	PHJ3K1C	TV-C202S
S	POWER	ICP	0801	87-001-132-080	0E	PROTECTOR, IC ICP-N38	PHJ3K1C	TV-C202S
O	POWER	L	0801	87-005-770-080	1A	COIL, 47UH K #7607	PHJ3K1C	TV-C202S
!	O POWER	L	0802	87-A90-586-010	1D	FLTR, LINE HL-28-153	PHJ3K1C	TV-C202S
S	POWER	PR	0801	87-A90-090-080	0E	PROTECTOR, 1.5A 491SERIES 60V	PHJ3K1C	TV-C202S
!	O POWER	PT	0801	86-LB4-655-010	1H	PT, KER S/W TRANS("20")	PHJ3K1C	TV-C202S
S	POWER	Q	0801	87-A30-114-080	1D	TR, 2SD1207TS	PHJ3K1C	TV-C202S
O	POWER	R	0110	87-A00-164-090	0E	RES, M/F 12K-2W J RSF(S)	PHJ3K1C	TV-C202S
O	POWER	R	0801	87-A00-555-010	1A	RES, CEM 2.2-10W J MPC722	PHJ3K1C	TV-C202S

PARTS LIST

! = Δ SAFTY PARTS
C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	POWER	R 0802	87-A00-171-090	0E	RES,M/F 82K-3W J	PHJ3K1C	TV-C202S
X	POWER	R 0803	88-121-222-080	0E	RES,2.2K-1/8W J	PHJ3K1C	TV-C202S
X	POWER	R 0804	88-121-122-080	0E	RES,1.2K-1/8W J	PHJ3K1C	TV-C202S
X	POWER	R 0805	88-121-472-080	0E	RES,4.7K-1/8W J	PHJ3K1C	TV-C202S
O	POWER	R 0806	87-A00-208-090	0E	RES,M/F 22-1/2W J RSF(S)	PHJ3K1C	TV-C202S
X	POWER	R 0807	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
O	POWER	R 0811	87-A00-283-090	0E	RES,M/F 0.27-2W J RSF(S)	PHJ3K1C	TV-C202S
O	POWER	R 0812	87-A00-224-090	0E	RES,SD 8.2M-1W J CE	PHJ3K1C	TV-C202S
X	POWER	R 0825	88-140-223-080	0E	RES,22K-1/2W J	PHJ3K1C	TV-C202S
X	POWER	R 0826	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X	POWER	R 0827	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
O	POWER	R 0828	87-A00-271-080	0E	RES,FUSE 100-1/8W RF16S	PHJ3K1C	TV-C202S
O	POWER	R 0829	87-A00-272-080	0E	RES,FUSE 1.8K-1/4W RF25S	PHJ3K1C	TV-C202S
X	POWER	R 0888	88-144-684-080	0E	RES,SD 680K-1/2W K	PHJ3K1C	TV-C202S
!	O POWER	SW 0801	87-A91-410-010	1B	SW,AC PUSH 1-1-1 ESB92SH1B	PHJ3K1C	TV-C202S
!	O PRINTS LOCAL	TH 0801	87-A90-830-010	1C	POS-THMS,PTH451C463BF9R0Q270	PHJ3K1C	TV-C202S
	O PRINTS LOCAL		86-LB4-903-010	1A	IB,PH (E) -C202S	PHJ3K1C	TV-C202S
X	PRINTS LOCAL		87-B40-086-010	0E	BAG,PV 0.04-230-400 PL	PHJ3K1C	TV-C202S
X	PWB		86-LB7-666-010	-	PWB,TV-66 CH	PHJ3K1C	TV-C202S
X	PWB,NK		86-LB7-667-010	-	PWB,NK-22 4M CH	PHJ3K1C	TV-C202S
X	PWB,OTHER		89-951-263-410	0E	WIRE,U24H1-26-5	PHJ3K1C	TV-C202S
X	PWB,OTHER		89-956-073-410	0E	WIRE,U24H6-7-5	PHJ3K1C	TV-C202S
X	PWB,OTHER		89-956-123-410	0E	WIRE,U24H6-12-5	PHJ3K1C	TV-C202S
X	PWB,OTHER		89-956-143-410	0E	WIRE,U24H6-14-5	PHJ3K1C	TV-C202S
X	PWB,OTHER		89-956-183-410	0E	WIRE,U24H6-18-5	PHJ3K1C	TV-C202S
X	PWB,OTHER	C 0215	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S
X	PWB,OTHER	C 0505	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S
X	PWB,OTHER	C 0515	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S
X	PWB,OTHER	CLP0001	87-A60-884-010	0E	PIN,DIAL COATING-SHS	PHJ3K1C	TV-C202S
X	PWB,OTHER	D 0011	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S
X	PWB,OTHER	D 0202	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0001	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0002	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0003	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0005	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0007	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0009	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0010	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0011	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0012	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0013	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0014	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0015	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0016	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0017	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0019	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0020	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0021	81-JT1-216-010	0E	EYELET,1.6-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0051	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0052	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0053	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0054	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0055	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0056	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0057	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0058	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0059	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0060	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0061	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0062	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0063	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	EY 0064	81-JT1-215-010	0E	EYELET2.0-3.0	PHJ3K1C	TV-C202S
X	PWB,OTHER	L 0202	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S
X	PWB,OTHER	L 0205	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S
X	PWB,OTHER	Q 0202	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S
X	PWB,OTHER	R 0076	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S
X	PWB,OTHER	R 0095	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S
X	PWB,OTHER	R 0201	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S
X	PWB,OTHER	R 0385	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S
X	PWB,OTHER	R 0617	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S

PARTS LIST

! = Δ SAFTY PARTS
C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	PWB, OTHER	R 0620	87-A80-061-010	0E	PLATING-JW, P15-5-7	PHJ3K1C	TV-C202S
X	PWB, OTHER	X 0201	88-100-000-010	0E	PLATING-JW, 0.58 SN95	PHJ3K1C	TV-C202S
O	SCREW		86-LBB-206-010	0E	S-SCREW, ASSY TV5-40 W20	PHJ3K1C	TV-C202S
O	SCREW		87-067-680-010	0E	BVIT3B+3-10	PHJ3K1C	TV-C202S
O	SCREW		87-067-758-010	0E	BVT2+3-12 W/O SL0T	PHJ3K1C	TV-C202S
O	SCREW		87-067-761-010	0E	BVT2+3-10 BLK	PHJ3K1C	TV-C202S
O	SCREW		87-067-844-010	0E	BVT2+4-16 BLK	PHJ3K1C	TV-C202S
O	SYSICON	C 0001	87-018-109-080	0E	CAP, TC U 22P-50 J SL UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0002	87-018-109-080	0E	CAP, TC U 22P-50 J SL UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0003	87-018-109-080	0E	CAP, TC U 22P-50 J SL UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0004	87-018-109-080	0E	CAP, TC U 22P-50 J SL UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0005	87-018-109-080	0E	CAP, TC U 22P-50 J SL UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0006	87-018-109-080	0E	CAP, TC U 22P-50 J SL UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0007	87-018-127-080	0E	CAP, TC U 470P-50 K B UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0008	87-018-123-080	0E	CAP, TC U 220P-50 K B UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0009	87-018-134-080	0E	CAP, TC U 0.01-16 N Y UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0010	87-A12-063-080	0E	CAP, E 220-10 SMG	PHJ3K1C	TV-C202S
O	SYSICON	C 0011	87-A12-091-080	0E	CAP, E 10-50 SMG	PHJ3K1C	TV-C202S
O	SYSICON	C 0012	87-018-119-080	0E	CAP, TC U 100P-50 K B UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0013	87-A12-083-080	0E	CAP, E 0.1-50 SMG	PHJ3K1C	TV-C202S
O	SYSICON	C 0014	87-018-115-080	0E	CAP, TC U 47P-50 J SL UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0015	87-018-119-080	0E	CAP, TC U 100P-50 K B UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0016	87-018-131-080	0E	CAP, TC U 1000P-50 K B UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0020	87-018-131-080	0E	CAP, TC U 1000P-50 K B UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0021	87-018-125-080	0E	CAP, TC U 330P-50 K B UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0023	87-A12-087-080	0E	CAP, E 1-50 SMG	PHJ3K1C	TV-C202S
O	SYSICON	C 0025	87-A12-090-080	0E	CAP, E 4.7-50 SMG	PHJ3K1C	TV-C202S
O	SYSICON	C 0026	87-A12-090-080	0E	CAP, E 4.7-50 SMG	PHJ3K1C	TV-C202S
O	SYSICON	C 0027	87-A12-087-080	0E	CAP, E 1-50 SMG	PHJ3K1C	TV-C202S
O	SYSICON	C 0028	87-A12-087-080	0E	CAP, E 1-50 SMG	PHJ3K1C	TV-C202S
O	SYSICON	C 0029	87-A12-090-080	0E	CAP, E 4.7-50 SMG	PHJ3K1C	TV-C202S
O	SYSICON	C 0040	87-018-131-080	0E	CAP, TC U 1000P-50 K B UP050	PHJ3K1C	TV-C202S
O	SYSICON	C 0357	87-A12-091-080	0E	CAP, E 10-50 SMG	PHJ3K1C	TV-C202S
O	SYSICON	D 0005	87-070-110-010	0E	LED, SLP-181B-51 RED	PHJ3K1C	TV-C202S
S	SYSICON	D 0012	87-A40-291-080	0E	DIODE, 1N4148M (CPT)	PHJ3K1C	TV-C202S
S	SYSICON	D 0014	87-A40-291-080	0E	DIODE, 1N4148M (CPT)	PHJ3K1C	TV-C202S
S	SYSICON	D 0018	87-A40-291-080	0E	DIODE, 1N4148M (CPT)	PHJ3K1C	TV-C202S
O	SYSICON	FB 0001	87-003-223-080	0E	F-BEAD, BL02RN2	PHJ3K1C	TV-C202S
O	SYSICON	HL 0005	84-LB3-216-010	0E	HLDR, LED	PHJ3K1C	TV-C202S
S	SYSICON	IC 0001	86-LB7-622-010	2A	IC, M37221M6-286SP	PHJ3K1C	TV-C202S
S	SYSICON	IC 0002	87-A21-845-080	1A	IC, KIA7042AP	PHJ3K1C	TV-C202S
S	SYSICON	IC 0003	87-A21-377-010	1A	IC, S-24C02BDP-1A	PHJ3K1C	TV-C202S
O	SYSICON	IC 0004	87-A91-538-010	1B	RCR UNIT, SBX1981-72P	PHJ3K1C	TV-C202S
S	SYSICON	Q 0003	87-A30-065-080	0E	TR, 2SC2785FE	PHJ3K1C	TV-C202S
S	SYSICON	Q 0004	87-026-218-080	0E	TR, DTC144ES	PHJ3K1C	TV-C202S
S	SYSICON	Q 0006	87-A30-121-080	0E	TR, DTC323TS	PHJ3K1C	TV-C202S
S	SYSICON	Q 0007	87-A30-121-080	0E	TR, DTC323TS	PHJ3K1C	TV-C202S
S	SYSICON	Q 0010	87-A30-065-080	0E	TR, 2SC2785FE	PHJ3K1C	TV-C202S
S	SYSICON	Q 0011	87-A30-065-080	0E	TR, 2SC2785FE	PHJ3K1C	TV-C202S
S	SYSICON	Q 0604	87-A30-065-080	0E	TR, 2SC2785FE	PHJ3K1C	TV-C202S
S	SYSICON	Q 0605	87-A30-065-080	0E	TR, 2SC2785FE	PHJ3K1C	TV-C202S
X	SYSICON	R 0001	88-121-102-080	0E	RES, 1K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0002	88-121-103-080	0E	RES, 10K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0003	88-121-222-080	0E	RES, 2.2K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0004	88-121-222-080	0E	RES, 2.2K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0005	88-121-332-080	0E	RES, 3.3K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0006	88-121-472-080	0E	RES, 4.7K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0007	88-121-103-080	0E	RES, 10K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0010	88-121-104-080	0E	RES, 100K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0011	88-121-223-080	0E	RES, 22K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0014	88-121-104-080	0E	RES, 100K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0015	88-121-102-080	0E	RES, 1K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0016	88-121-473-080	0E	RES, 47K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0024	88-121-472-080	0E	RES, 4.7K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0025	88-121-333-080	0E	RES, 33K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0026	88-121-103-080	0E	RES, 10K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0027	88-121-473-080	0E	RES, 47K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0028	88-121-103-080	0E	RES, 10K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0029	88-121-102-080	0E	RES, 1K-1/8W J	PHJ3K1C	TV-C202S
X	SYSICON	R 0030	88-121-393-080	0E	RES, 39K-1/8W J	PHJ3K1C	TV-C202S

PARTS LIST

! = Δ SAFTY PARTS
C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X	SYSCON	R 0031	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0032	88-121-823-080	0E	RES,82K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0033	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0034	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0035	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0036	88-121-153-080	0E	RES,15K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0037	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0038	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0039	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0040	88-121-822-080	0E	RES,8.2K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0041	88-121-183-080	0E	RES,18K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0042	88-121-123-080	0E	RES,12K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0043	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0044	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0046	88-121-273-080	0E	RES,27K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0047	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0049	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0052	88-121-824-080	0E	RES,820K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0054	88-121-682-080	0E	RES,6.8K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0055	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0056	88-121-472-080	0E	RES,4.7K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0057	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0060	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0075	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0077	88-121-331-080	0E	RES,330-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0078	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0079	88-121-474-080	0E	RES,470K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0080	88-121-104-080	0E	RES,100K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0081	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0082	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0096	88-121-104-080	0E	RES,100K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0347	88-121-472-080	0E	RES,4.7K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0348	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0349	88-121-472-080	0E	RES,4.7K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0350	88-121-472-080	0E	RES,4.7K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0351	88-121-272-080	0E	RES,2.7K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0601	88-121-100-080	0E	RES,10-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0610	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	SYSCON	R 0621	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
O	SYSCON	SFR0001	87-024-438-080	0E	SFR,220K H RH063MC	PHJ3K1C	TV-C202S
O	SYSCON	SFR0002	87-024-357-080	0E	SFR,100K H EVN DJAA03	PHJ3K1C	TV-C202S
X	SYSCON	SH 0001	84-LB3-235-010	0E	SHLD-PLATE,MC	PHJ3K1C	TV-C202S
O	SYSCON	SW 0002	87-A90-712-080	0E	SW,TACT EVQ11L07K	PHJ3K1C	TV-C202S
O	SYSCON	SW 0003	87-A90-712-080	0E	SW,TACT EVQ11L07K	PHJ3K1C	TV-C202S
O	SYSCON	SW 0004	87-A90-712-080	0E	SW,TACT EVQ11L07K	PHJ3K1C	TV-C202S
O	SYSCON	SW 0005	87-A90-712-080	0E	SW,TACT EVQ11L07K	PHJ3K1C	TV-C202S
O	SYSCON	SW 0006	87-A90-712-080	0E	SW,TACT EVQ11L07K	PHJ3K1C	TV-C202S
O	SYSCON	X 0001	87-030-212-080	1A	VIB,CER 8.000MHZ CST	PHJ3K1C	TV-C202S
O	TUNER	C 0101	87-A12-087-080	0E	CAP,E 1-50 SMG	PHJ3K1C	TV-C202S
O	TUNER	C 0102	87-A12-072-080	0E	CAP,E 100-25 SMG	PHJ3K1C	TV-C202S
O	TUNER	C 0103	87-A11-132-080	0E	CAP,TC U 0.01-50 K B	PHJ3K1C	TV-C202S
O	TUNER	C 0104	87-018-119-080	0E	CAP,TC U 100P-50 K B UP050	PHJ3K1C	TV-C202S
X	TUNER	C 0105	88-700-919-810	0E	CAP,M 0.1-50 J	PHJ3K1C	TV-C202S
X	TUNER	C 0106	88-700-869-810	0E	CAP,M 0.068-50 J	PHJ3K1C	TV-C202S
X	TUNER	C 0107	88-700-859-810	0E	CAP,M 0.047-50 J	PHJ3K1C	TV-C202S
O	TUNER	C 0212	87-A12-087-080	0E	CAP,E 1-50 SMG	PHJ3K1C	TV-C202S
O	TUNER	C 0213	87-A12-072-080	0E	CAP,E 100-25 SMG	PHJ3K1C	TV-C202S
O	TUNER	C 0214	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C	TV-C202S
X	TUNER	C 0216	88-700-839-810	0E	CAP,M 0.022-50 J	PHJ3K1C	TV-C202S
O	TUNER	C 0218	87-018-133-080	0E	CAP,TC U 4700P-16 N X UP050	PHJ3K1C	TV-C202S
O	TUNER	C 0219	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C	TV-C202S
X	TUNER	C 0220	88-700-819-810	0E	CAP,M 0.01-50 J	PHJ3K1C	TV-C202S
O	TUNER	C 0221	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C	TV-C202S
O	TUNER	C 0222	87-018-121-080	0E	CAP,TC U 150P-50 K B UP050	PHJ3K1C	TV-C202S
O	TUNER	C 0223	87-A12-087-080	0E	CAP,E 1-50 SMG	PHJ3K1C	TV-C202S
X	TUNER	C 0224	88-700-819-810	0E	CAP,M 0.01-50 J	PHJ3K1C	TV-C202S
O	TUNER	C 0225	87-018-119-080	0E	CAP,TC U 100P-50 K B UP050	PHJ3K1C	TV-C202S
O	TUNER	FL 0201	87-A90-337-010	1C	FLTR,SAW OFW-K2959M	PHJ3K1C	TV-C202S
O	TUNER	FL 0203	87-A90-223-080	1A	FLTR, SFSH6.0MCB	PHJ3K1C	TV-C202S
O	TUNER	FL 0205	87-A90-224-080	0E	FLTR, TPS6.0MB	PHJ3K1C	TV-C202S

PARTS LIST

! =  SAFTY PARTS
C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	TUNER	FL 0206	87-008-577-080	1A	FLTR,TPS5.5MB2	PHJ3K1C	TV-C202S
O	TUNER	FL 0210	87-008-575-080	1A	FLTR,CFSFSH5.5MCB	PHJ3K1C	TV-C202S
S	TUNER	IC 0101	87-A20-371-080	0E	IC,KA33V	PHJ3K1C	TV-C202S
S	TUNER	IC 0201	87-A20-436-010	1E	IC,LA7565N	PHJ3K1C	TV-C202S
O	TUNER	L 0101	87-005-610-080	0E	COIL,47UH J LAV35	PHJ3K1C	TV-C202S
O	TUNER	L 0206	87-005-645-080	—	COIL,6.8UH K LF5.0S	PHJ3K1C	TV-C202S
O	TUNER	L 0207	87-005-684-080	0E	COIL,10UH J LF5.0S	PHJ3K1C	TV-C202S
O	TUNER	L 0210	86-LB7-659-010	0E	COIL,VCO3 38.0MHZ LA7565N	PHJ3K1C	TV-C202S
O	TUNER	L 0221	87-005-684-080	0E	COIL,10UH J LF5.0S	PHJ3K1C	TV-C202S
S	TUNER	Q 0101	87-A30-090-080	0E	FET,2SK2541	PHJ3K1C	TV-C202S
S	TUNER	Q 0102	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	TUNER	Q 0205	87-A30-066-080	0E	TR,2SA1175FE	PHJ3K1C	TV-C202S
S	TUNER	Q 0207	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	TUNER	Q 0208	87-A30-066-080	0E	TR,2SA1175FE	PHJ3K1C	TV-C202S
X	TUNER	R 0101	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0103	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0106	88-121-273-080	0E	RES,27K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0107	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0108	88-121-334-080	0E	RES,330K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0109	88-121-222-080	0E	RES,2.2K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0211	88-121-221-080	0E	RES,220-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0215	88-121-680-080	0E	RES,68-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0218	88-121-152-080	0E	RES,1.5K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0219	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0220	88-121-331-080	0E	RES,330-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0221	88-121-391-080	0E	RES,390-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0222	88-121-221-080	0E	RES,220-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0226	88-121-104-080	0E	RES,100K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0227	88-121-333-080	0E	RES,33K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0228	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0229	88-121-472-080	0E	RES,4.7K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0230	88-121-472-080	0E	RES,4.7K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0231	88-121-472-080	0E	RES,4.7K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0232	88-121-222-080	0E	RES,2.2K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0234	88-121-822-080	0E	RES,8.2K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0235	88-121-562-080	0E	RES,5.6K-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0236	88-121-105-080	0E	RES,1M-1/8W J	PHJ3K1C	TV-C202S
X	TUNER	R 0237	88-121-221-080	0E	RES,220-1/8W J	PHJ3K1C	TV-C202S
O	TUNER	SFR0201	87-024-354-080	0E	SFR,22K H EVN DJAA03	PHJ3K1C	TV-C202S
O	TUNER	TU 0101	87-A91-904-010	2P	TU UNIT, TUAWF4EG-761	PHJ3K1C	TV-C202S
O	TV	C 0030	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C	TV-C202S
O	TV	C 0301	87-018-122-080	0E	CAP,TC U 180P-50 K B UP050	PHJ3K1C	TV-C202S
O	TV	C 0302	87-018-122-080	0E	CAP,TC U 180P-50 K B UP050	PHJ3K1C	TV-C202S
O	TV	C 0303	87-018-122-080	0E	CAP,TC U 180P-50 K B UP050	PHJ3K1C	TV-C202S
X	TV	C 0304	88-254-100-810	0E	CAP,CER 10P-50 D CH	PHJ3K1C	TV-C202S
O	TV	C 0307	87-A11-148-080	0E	CAP,TC U 0.1-50 Z F	PHJ3K1C	TV-C202S
X	TV	C 0308	88-254-070-810	0E	CAP,CER 7P-50 J C	PHJ3K1C	TV-C202S
O	TV	C 0309	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C	TV-C202S
O	TV	C 0310	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C	TV-C202S
O	TV	C 0311	87-A11-148-080	0E	CAP,TC U 0.1-50 Z F	PHJ3K1C	TV-C202S
O	TV	C 0312	87-A12-086-080	0E	CAP,E 0.47-50 SMG	PHJ3K1C	TV-C202S
O	TV	C 0313	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C	TV-C202S
O	TV	C 0314	87-018-122-080	0E	CAP,TC U 180P-50 K B UP050	PHJ3K1C	TV-C202S
O	TV	C 0315	87-018-107-080	0E	CAP,TC U 18P-50 J SL UP050	PHJ3K1C	TV-C202S
O	TV	C 0316	87-018-131-080	0E	CAP,TC U 1000P-50 K B UP050	PHJ3K1C	TV-C202S
X	TV	C 0317	88-700-989-810	0E	CAP,M 0.056-50 J	PHJ3K1C	TV-C202S
X	TV	C 0318	88-700-989-810	0E	CAP,M 0.056-50 J	PHJ3K1C	TV-C202S
X	TV	C 0319	88-700-819-810	0E	CAP,M 0.01-50 J	PHJ3K1C	TV-C202S
O	TV	C 0320	87-010-529-080	0E	CAP,E 1-50 M BP	PHJ3K1C	TV-C202S
X	TV	C 0321	88-700-819-810	0E	CAP,M 0.01-50 J	PHJ3K1C	TV-C202S
X	TV	C 0322	88-700-989-810	0E	CAP,M 0.056-50 J	PHJ3K1C	TV-C202S
X	TV	C 0323	88-254-210-810	0E	CAP,CER 22P-50 J CH	PHJ3K1C	TV-C202S
X	TV	C 0324	88-254-250-810	0E	CAP,CER 33P-50 J CH	PHJ3K1C	TV-C202S
O	TV	C 0325	87-A12-087-080	0E	CAP,E 1-50 SMG	PHJ3K1C	TV-C202S
X	TV	C 0326	88-700-819-810	0E	CAP,M 0.01-50 J	PHJ3K1C	TV-C202S
O	TV	C 0327	87-016-251-080	0E	CAP,E 220-16 M SMG	PHJ3K1C	TV-C202S
O	TV	C 0328	87-018-195-080	0E	CAP,TC U 1200P-16 N X UP050	PHJ3K1C	TV-C202S
O	TV	C 0329	87-A12-087-080	0E	CAP,E 1-50 SMG	PHJ3K1C	TV-C202S
O	TV	C 0330	87-018-124-080	0E	CAP,TC U 270P-50 K B UP050	PHJ3K1C	TV-C202S
X	TV	C 0331	88-700-839-810	0E	CAP,M 0.022-50 J	PHJ3K1C	TV-C202S

PARTS LIST

! =  SAFETY PARTS
C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
O	TV	C	0332	87-A12-089-080	0E	CAP,E 3.3-50 SMG	PHJ3K1C TV-C202S
X	TV	C	0333	88-700-709-810	0E	CAP,M 3300P-50 J	PHJ3K1C TV-C202S
X	TV	C	0334	88-700-839-810	0E	CAP,M 0.022-50 J	PHJ3K1C TV-C202S
O	TV	C	0335	87-A10-918-080	0E	CAP,E 100-16 SMG	PHJ3K1C TV-C202S
O	TV	C	0336	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C TV-C202S
X	TV	C	0337	88-700-819-810	0E	CAP,M 0.01-50 J	PHJ3K1C TV-C202S
O	TV	C	0339	87-018-116-080	0E	CAP,TC U 56P-50 J SL UP050	PHJ3K1C TV-C202S
O	TV	C	0340	87-A12-086-080	0E	CAP,E 0.47-50 SMG	PHJ3K1C TV-C202S
O	TV	C	0341	87-A12-086-080	0E	CAP,E 0.47-50 SMG	PHJ3K1C TV-C202S
O	TV	C	0342	87-A12-086-080	0E	CAP,E 0.47-50 SMG	PHJ3K1C TV-C202S
X	TV	C	0343	88-700-839-810	0E	CAP,M 0.022-50 J	PHJ3K1C TV-C202S
O	TV	C	0344	87-A12-087-080	0E	CAP,E 1-50 SMG	PHJ3K1C TV-C202S
X	TV	C	0345	88-700-839-810	0E	CAP,M 0.022-50 J	PHJ3K1C TV-C202S
X	TV	C	0346	88-700-839-810	0E	CAP,M 0.022-50 J	PHJ3K1C TV-C202S
O	TV	C	0347	87-A12-090-080	0E	CAP,E 4.7-50 SMG	PHJ3K1C TV-C202S
O	TV	C	0348	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C TV-C202S
O	TV	C	0349	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C TV-C202S
O	TV	C	0350	87-018-123-080	0E	CAP,TC U 220P-50 K B UP050	PHJ3K1C TV-C202S
O	TV	C	0351	87-A12-087-080	0E	CAP,E 1-50 SMG	PHJ3K1C TV-C202S
O	TV	C	0352	87-A12-087-080	0E	CAP,E 1-50 SMG	PHJ3K1C TV-C202S
X	TV	C	0353	88-700-919-810	0E	CAP,M 0.1-50 J	PHJ3K1C TV-C202S
O	TV	C	0354	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C TV-C202S
X	TV	C	0355	88-700-919-810	0E	CAP,M 0.1-50 J	PHJ3K1C TV-C202S
O	TV	C	0356	87-018-122-080	0E	CAP,TC U 180P-50 K B UP050	PHJ3K1C TV-C202S
O	TV	C	0358	87-A12-066-080	0E	CAP,E 47-16 SMG	PHJ3K1C TV-C202S
O	TV	C	0359	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C TV-C202S
O	TV	C	0360	87-A12-091-080	0E	CAP,E 10-50 SMG	PHJ3K1C TV-C202S
O	TV	C	0363	87-016-459-080	0E	CAP,E 470-10 M SMG	PHJ3K1C TV-C202S
O	TV	C	0364	87-A12-091-080	0E	CAP,E 10-50 SMG	PHJ3K1C TV-C202S
X	TV	C	0367	88-254-250-810	0E	CAP,CER 33P-50 J CH	PHJ3K1C TV-C202S
X	TV	C	0368	88-254-250-810	0E	CAP,CER 33P-50 J CH	PHJ3K1C TV-C202S
X	TV	C	0369	88-254-150-810	0E	CAP,CER 15P-50 J CH	PHJ3K1C TV-C202S
O	TV	C	0370	87-010-379-080	0E	CAP,E 22-16 M 11L SME	PHJ3K1C TV-C202S
O	TV	C	0371	87-A12-090-080	0E	CAP,E 4.7-50 SMG	PHJ3K1C TV-C202S
O	TV	C	0372	87-A12-090-080	0E	CAP,E 4.7-50 SMG	PHJ3K1C TV-C202S
O	TV	C	0373	87-018-115-080	0E	CAP,TC U 47P-50 J SL UP050	PHJ3K1C TV-C202S
O	TV	C	0374	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C TV-C202S
O	TV	C	0375	87-018-134-080	0E	CAP,TC U 0.01-16 N Y UP050	PHJ3K1C TV-C202S
X	TV	C	0376	88-214-810-810	0E	CAP,CER 0.01-50 M Y	PHJ3K1C TV-C202S
O	TV	C	0377	87-A12-071-080	0E	CAP,E 47-25 SMG	PHJ3K1C TV-C202S
O	TV	C	0378	87-A12-087-080	0E	CAP,E 1-50 SMG	PHJ3K1C TV-C202S
O	TV	C	0379	87-A12-090-080	0E	CAP,E 4.7-50 SMG	PHJ3K1C TV-C202S
O	TV	C	0399	87-A10-211-010	0E	CAP,CER 0.1-50 M	PHJ3K1C TV-C202S
S	TV	D	0007	87-A40-291-080	0E	DIODE,1N4148M (CPT)	PHJ3K1C TV-C202S
S	TV	D	0008	87-A40-291-080	0E	DIODE,1N4148M (CPT)	PHJ3K1C TV-C202S
S	TV	D	0009	87-A40-291-080	0E	DIODE,1N4148M (CPT)	PHJ3K1C TV-C202S
S	TV	D	0301	87-A40-757-080	0E	ZENER,UZ7.5BSC	PHJ3K1C TV-C202S
S	TV	D	0302	87-A40-001-080	0E	ZENER,MTZJ12C	PHJ3K1C TV-C202S
S	TV	D	0303	87-A40-235-080	0E	ZENER,MTZJ9.1C	PHJ3K1C TV-C202S
S	TV	D	0304	87-A40-348-080	0E	ZENER,MTZJ3.3A	PHJ3K1C TV-C202S
S	TV	D	0371	87-A40-291-080	0E	DIODE,1N4148M (CPT)	PHJ3K1C TV-C202S
S	TV	D	0372	87-A40-291-080	0E	DIODE,1N4148M (CPT)	PHJ3K1C TV-C202S
O	TV	DL	0301	84-LB3-638-010	1D	DL,ADL-CP144E	PHJ3K1C TV-C202S
O	TV	DL	0302	87-A90-370-010	1B	DELAY LINE,ELB10Z334	PHJ3K1C TV-C202S
O	TV	FL	0301	84-LB3-668-010	1A	FLTR,SECAM DET	PHJ3K1C TV-C202S
O	TV	FL	0302	84-LB3-668-010	1A	FLTR,SECAM DET	PHJ3K1C TV-C202S
O	TV	FL	0304	82-JT2-611-010	1A	FLTR,SECAM REF	PHJ3K1C TV-C202S
O	TV	FL	0305	84-LB3-622-010	1A	FLTR,BELL 2 S-10E	PHJ3K1C TV-C202S
S	TV	IC	0301	87-070-080-010	2M	IC,TA8759BN	PHJ3K1C TV-C202S
S	TV	IC	0302	87-027-938-010	1B	IC,TC4053BP	PHJ3K1C TV-C202S
O	TV	L	0303	82-JT2-608-010	1A	FLTR,DL PHASE	PHJ3K1C TV-C202S
O	TV	L	0304	87-005-646-080	-	COIL,8.2UH K LF5.0S	PHJ3K1C TV-C202S
O	TV	L	0306	87-005-611-080	0E	COIL,56UH J LAV35	PHJ3K1C TV-C202S
O	TV	L	0308	87-005-688-080	0E	COIL,22UH J LF5.0S	PHJ3K1C TV-C202S
O	TV	L	0309	87-005-693-080	0E	COIL,56UH J LF5.0S	PHJ3K1C TV-C202S
O	TV	L	0310	87-005-602-080	0E	COIL,10UH J LAV35	PHJ3K1C TV-C202S
S	TV	Q	0012	87-026-218-080	0E	TR,DTC144ES	PHJ3K1C TV-C202S
S	TV	Q	0013	87-026-218-080	0E	TR,DTC144ES	PHJ3K1C TV-C202S
S	TV	Q	0014	87-026-218-080	0E	TR,DTC144ES	PHJ3K1C TV-C202S
S	TV	Q	0015	87-A30-066-080	0E	TR,2SA1175FE	PHJ3K1C TV-C202S

PARTS LIST

! =  SAFTY PARTS
C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.

Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
S	TV	Q 0016	87-A30-066-080	0E	TR,2SA1175FE	PHJ3K1C	TV-C202S
S	TV	Q 0301	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	TV	Q 0302	87-A30-066-080	0E	TR,2SA1175FE	PHJ3K1C	TV-C202S
S	TV	Q 0304	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	TV	Q 0305	87-A30-066-080	0E	TR,2SA1175FE	PHJ3K1C	TV-C202S
S	TV	Q 0306	87-A30-121-080	0E	TR,DTC323TS	PHJ3K1C	TV-C202S
S	TV	Q 0307	87-A30-066-080	0E	TR,2SA1175FE	PHJ3K1C	TV-C202S
S	TV	Q 0309	87-026-218-080	0E	TR,DTC144ES	PHJ3K1C	TV-C202S
S	TV	Q 0310	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	TV	Q 0311	84-LB2-699-080	0E	TR,2SC945A(C)-T	PHJ3K1C	TV-C202S
S	TV	Q 0312	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	TV	Q 0314	87-026-502-080	0E	TR,DTC144TS	PHJ3K1C	TV-C202S
S	TV	Q 0315	87-026-218-080	0E	TR,DTC144ES	PHJ3K1C	TV-C202S
S	TV	Q 0316	87-A30-066-080	0E	TR,2SA1175FE	PHJ3K1C	TV-C202S
S	TV	Q 0317	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	TV	Q 0318	87-A30-121-080	0E	TR,DTC323TS	PHJ3K1C	TV-C202S
S	TV	Q 0319	87-A30-090-080	0E	FET,2SK2541	PHJ3K1C	TV-C202S
S	TV	Q 0320	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	TV	Q 0322	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	TV	Q 0371	87-A30-066-080	0E	TR,2SA1175FE	PHJ3K1C	TV-C202S
S	TV	Q 0372	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	TV	Q 0373	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
S	TV	Q 0502	87-A30-065-080	0E	TR,2SC2785FE	PHJ3K1C	TV-C202S
X	TV	R 0022	88-121-682-080	0E	RES,6.8K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0063	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0064	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0065	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0066	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0067	88-121-333-080	0E	RES,33K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0069	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0070	88-121-682-080	0E	RES,6.8K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0071	88-121-472-080	0E	RES,4.7K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0301	88-121-561-080	0E	RES,560-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0302	88-121-822-080	0E	RES,8.2K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0303	88-121-272-080	0E	RES,2.7K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0304	88-121-822-080	0E	RES,8.2K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0305	88-121-391-080	0E	RES,390-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0306	88-121-222-080	0E	RES,2.2K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0307	88-121-334-080	0E	RES,330K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0308	88-121-821-080	0E	RES,820-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0309	88-121-472-080	0E	RES,4.7K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0310	88-121-272-080	0E	RES,2.7K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0311	88-121-392-080	0E	RES,3.9K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0312	88-121-821-080	0E	RES,820-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0313	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0314	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0315	88-121-823-080	0E	RES,82K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0316	88-121-334-080	0E	RES,330K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0317	88-121-274-080	0E	RES,270K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0318	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0319	88-121-561-080	0E	RES,560-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0320	88-121-273-080	0E	RES,27K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0321	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0322	88-121-332-080	0E	RES,3.3K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0323	88-121-471-080	0E	RES,470-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0324	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0325	88-121-471-080	0E	RES,470-1/8W J	PHJ3K1C	TV-C202S
O	TV	R 0326	87-A00-067-090	0E	RES,M/F 6.8K-3W J	PHJ3K1C	TV-C202S
X	TV	R 0327	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0328	88-121-821-080	0E	RES,820-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0329	88-121-821-080	0E	RES,820-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0330	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0331	88-121-222-080	0E	RES,2.2K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0332	88-121-332-080	0E	RES,3.3K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0333	88-121-820-080	0E	RES,82-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0334	88-121-151-080	0E	RES,150-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0335	88-121-561-080	0E	RES,560-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0336	88-121-822-080	0E	RES,8.2K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0338	88-121-152-080	0E	RES,1.5K-1/8W J	PHJ3K1C	TV-C202S
X	TV	R 0339	88-121-152-080	0E	RES,1.5K-1/8W J	PHJ3K1C	TV-C202S

PARTS LIST

! =  SAFETY PARTS
C = Components marked

All components used on this model at the production line are shown in this service manual.

However, please note that not all components will be available as spare parts for after-sales service.


Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.

Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

K NO. = Only use Japanese.

! C	UNIT NAME	REF NO.	PARTS CODE	K NO.	DESCRIPTION	SUFFIX	MODEL NAME
X TV		R 0340	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0341	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0342	88-121-822-080	0E	RES,8.2K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0343	88-121-104-080	0E	RES,100K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0344	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0345	88-130-471-080	0E	RES,470-1/4W J	PHJ3K1C	TV-C202S
X TV		R 0346	88-121-221-080	0E	RES,220-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0352	88-121-152-080	0E	RES,1.5K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0353	88-121-333-080	0E	RES,33K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0354	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0356	88-121-750-080	0E	RES,75-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0358	88-121-680-080	0E	RES,68-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0359	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0360	88-121-221-080	0E	RES,220-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0361	88-121-750-080	0E	RES,75-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0363	88-121-101-080	0E	RES,100-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0365	88-121-470-080	0E	RES,47-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0366	88-121-271-080	0E	RES,270-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0367	88-121-470-080	0E	RES,47-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0368	88-121-470-080	0E	RES,47-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0369	88-121-221-080	0E	RES,220-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0370	88-121-124-080	0E	RES,120K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0371	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0372	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0373	88-121-563-080	0E	RES,56K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0374	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0375	88-121-332-080	0E	RES,3.3K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0376	88-121-102-080	0E	RES,1K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0377	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0378	88-121-563-080	0E	RES,56K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0379	88-121-153-080	0E	RES,15K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0380	88-121-821-080	0E	RES,820-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0381	88-121-124-080	0E	RES,120K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0382	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0384	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0386	88-130-471-080	0E	RES,470-1/4W J	PHJ3K1C	TV-C202S
X TV		R 0387	88-121-472-080	0E	RES,4.7K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0388	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0389	88-121-221-080	0E	RES,220-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0390	88-121-121-080	0E	RES,120-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0397	88-121-822-080	0E	RES,8.2K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0398	88-121-104-080	0E	RES,100K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0399	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0515	88-121-473-080	0E	RES,47K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0516	88-121-274-080	0E	RES,270K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0901	88-121-225-080	0E	RES,2.2M-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0902	88-121-103-080	0E	RES,10K-1/8W J	PHJ3K1C	TV-C202S
X TV		R 0903	88-121-223-080	0E	RES,22K-1/8W J	PHJ3K1C	TV-C202S
O TV		SFR0301	87-024-349-080	0E	SFR,1K H EVN DJAA03	PHJ3K1C	TV-C202S
O TV		SFR0302	87-024-349-080	0E	SFR,1K H EVN DJAA03	PHJ3K1C	TV-C202S
O TV		SFR0501	87-024-357-080	0E	SFR,100K H EVN DJAA03	PHJ3K1C	TV-C202S
O TV		X 0301	87-A70-054-080	1B	VIB,XTAL 4.43MHZ AQC-1018	PHJ3K1C	TV-C202S
O TV		X 0302	87-030-327-010	0E	VIB,CER 503.500KHZ CSB F30	PHJ3K1C	TV-C202S
O TV		X 0303	87-A70-007-080	1B	VIB,XTAL 3.58MHZ AQC-1001	PHJ3K1C	TV-C202S

SCHEMATIC DIAGRAM (MAIN / NK)



アイワ株式会社 〒110-8710 東京都台東区池之端1-2-11 ☎03(3827)3111 (代表)
AIWA CO.,LTD. 2-11, IKENOHATA 1-CHOME, TAITO-KU, TOKYO 110, JAPAN TEL:03 (3827) 3111