

Software Update LE510E

Please copy below files to USB memory (root)

- MB60_en.bin
- usb_auto_update_T4.txt
- mboot.bin (not always)

Procedure of Software Update

1. Turn the TV power off by mechanical switch (rocker switch) or removing AC plug
2. Connect the USB memory to the TV.
3. Press „OK“ button from Remote control and turn the TV on (by mechanical switch or inserting AC plug) → keep OK button pressed until the Standby LED blinks rapidly (this blinking is much faster than normal blinking)
4. You can release the „OK“ button. The screen keeps dark and LED is blinking.
5. After approximately 1-2 minutes the LED stops to blinking and TV starts with new Software.