




- 1.卡门 : CD DOOR
- 2.镜片 : Lens
- 3.面壳: FRONT PANEL
- 4.面壳PCB: FRONT PANEL-PCB
- 5.按键: KEY SWITCH
- 6.高密度海绵脚垫: MAT FOR MACHINE FEET
- 7.机芯: LODER
- 8.线扣: firmware-line
- 9.上盖: TOP COVER
- 10.后板: REAR PANEL
- 11.解码板: DECODER
- 12.电源板: POWER BOARD
- 13.咪板: MIC BOARD
- 14.底板: BOTTOM CABINET

DV117SI