

TP.MS3463S.PB801


Trouble Shooting

- Power supply**
- Display**
- Audio**
- Function**


TV Author : SHITENG WANG
POWER Author : ZHIAN HE

Checked By :
Checked By :


1. Power Supply Block diagram




2. Power Supply Trouble




3. Power supply for LED drive




4. Main board Power Supply Trouble




5. Display Trouble (blurred screen)




6. Display Trouble (white screen)




7. Display Trouble (black screen)




8. Audio Trouble (No sound)




9. Function Trouble (TV video)




10. Function Trouble (PC)



11. Function Trouble (HDMI、YPbPr、CVBS)





SCART Input

