




ITEM	PART NO.	PART NAME	QTY.
1	64CC031AAG	MPH (MP FOOT)	4
2	88CC151AAG	电池门 (BATTERY DOOR)	1
3	88CC171AAG	铁支架盖板 (BATTERY DOOR)	1
4	33667799BG	电池 (BATTERY)	1
5	87CC031AAG	铁支架 (PRESS BACK PLATE)	1
6	88CC181AAG	USB 盖板 (USB INSERT COVER)	1
7	64CC021AAG	USB 底座 (USB INSERT)	1
8	34CC33100G	机芯 (DVD PICKUP)	1
9	82CC22010G	按键背面板 (KEY PCB)	1
10	82CC61010G	解码板 (MP MP4)	1
11	64CC051AAG	铁板按键 (KEY PLATE)	1
12	88CC061AAG	铁板按键 (KEY PLATE)	1
13	88CC121AAG	指示灯 (LED GLASS)	1
14	88CC141AAG	指示灯 (LED GLASS)	1
15	88CC19100G	铁板按键 (KEY PLATE)	1
16	64CC011AAG	喇叭 (SPEAKER)	2
17	374410900G	喇叭 (SPEAKER)	2
18	87CC041AAG	显示屏 (GLASS MON)	1
19	118285010G	显示屏 (GLASS MON)	1
20	88CC051AAG	LCD 上盖 (LCD TOP)	1
21	87CC02100G	后壳铝板 (PRESS DECO PLATE)	1
22	82CC27010G	MONITOR PCB	1
23	88CC041AAG	LCD 下盖 (LCD BOTTOM)	1
24	64CC041AAG	CD 门轴 (CD DOOR RUBBER)	1
25	88CC031AAG	扣簧 (CD DOOR)	1
26	55CC20010G	扣簧 (CD DOOR)	1
27	88CC101AAG	CD 门支架 (DOOR BRACKET)	1
28	87CC01100G	HINGE	1
29	88CC071AAG	OPN 按钮 (OPEN KNOB)	1
30	88CC021AAG	MP 指示灯 (MP TOP)	1
31	88CC081AAG	开合滑扣 (OPEN KNOB)	1
32	88CC091AAG	滑扣支架 (SLIDE LOCK)	1
33	55CC10010G	压簧 (C-SPRING)	1
34	88CC131AAG	遥控窗 (IR WINDOW)	1
35	82CC23010G	JACK PCB	1
36	88CC111AAG	POWER 按钮 (POWER KNOB)	1
37	88CC011AAG	MP 指示灯 (MP BOTTOM)	1
38	88CC161AAG	机芯支架 (DOCK BRACKET)	1

MATERIAL		T O L E R A N C E	
COLOR		>0≤4	0.05 0.10 0.20
FINISH		>4≤16	0.08 0.15 0.30
Q'TY	1	>16≤63	0.12 0.25 0.50
		>63≤200	0.20 0.40 0.80
		>200--	0.40 0.80 1.50
UNIT	SCALE	MODEL	APPR. CHECK PREP.
mm		MTD-9858KA	宋俊
TITLE			
MTD-9858KA			
EXPLODE			
DRAWING NO.			
0			
1ST ISSUE	SJ	09-08-24	
REV.	CHANGE DESCRIPTION	BY	DATE

PC TION

TECHNOLOGY(SZ) CO., LTD