

Ref No. MODE	IC6701																			
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
CD PLAY	-28.2	-24.8	-21.3	-17.9	-21.4	-14.5	-24.8	-21.3	-24.7	-24.7	-21.3	-24.7	-23.1	-24.7	-21.3	-24.7	-24.7	-28	-18	-21.3
STANDBY	-28.2	-24.8	-21.3	-17.9	-21.4	-14.5	-24.8	-21.3	-24.7	-24.7	-21.3	-24.7	-23.1	-24.7	-21.3	-24.7	-24.7	-28	-18	-21.3
Ref No. MODE	IC6701																			
	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
CD PLAY	-21.3	-21.3	-24.8	-28.1	-28.1	-24.8	-21.8	-28.1	-28.1	-21.3	-25	-25.2	-25	-25	-25	-25	-25	-25.1	-25.1	-25.1
STANDBY	-21.3	-21.3	-24.8	-28.1	-28.1	-24.8	-21.8	-28.1	-28.1	-21.3	-25	-25.2	-25	-25	-25	-25	-25	-25.1	-25.1	-25.1
Ref No. MODE	IC6701																			
	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
CD PLAY	-28	-28	-28	-28	-28	-28	-28	-28	0	2.2	2.1	5.1	4.2	4.8	0.1	4.7	0	0	-7.6	-11
STANDBY	-28	-28	-28	-28	-28	-28	-28	-28	0	2.2	2.1	5.1	4.2	4.8	0.1	4.7	0	0	-7.6	-11
Ref No. MODE	IC6701																			
	61	62	63	64																
CD PLAY	-17.9	-17.9	-28	-21.3																
STANDBY	-21.3	-21.3	-17.9	-24.8																
Ref No. MODE	IC6702																			
	1	2	3	4	5	6	7	8												
CD PLAY	0	0	0	-7	0	0	0	7.1												
STANDBY	0	0	0	-7	0	0	0	7.1												
Ref No. MODE	Q6601				Q6602				Q6603				Q6604				Q6701			
	E	C	B		E	C	B		E	C	B		E	C	B		E	C	B	
CD PLAY	0	12	0		0	12	0		12	0	12		12	0	12		0	0.1	0	
STANDBY	0	12	0		0	12	0		12	0	12		12	0	12		0	0.1	0	
Ref No. MODE	Q6702				Q6703				Q6704				Q6705				Q6801			
	E	C	B		E	C	B		E	C	B		E	C	B		E	C	B	
CD PLAY	0	5.1	-1.1		0	0.1	5		0	0.1	5		0	0.1	5		0	0	-2.2	
STANDBY	0	5.1	-1.1		0	0.1	5		0	0.1	5		0	0.1	5		0	0	0.7	
Ref No. MODE	Q6802				Q6803															
	E	C	B		E	C	B													
CD PLAY	0	0	0		0	-2.2	0													
STANDBY	0	0	0.7		1.1	1.1	0													