


➡ : DVD RF SIGNAL LINE 📡 : DVD AUDIO SIGNAL LINE 📶 : MAIN SIGNAL LINE 📡 : USB SIGNAL LINE



SA-VK760EE
DVD (AUDIO) BLOCK DIAGRAM