


18.1. DVD Module Circuit

A DVD MODULE CIRCUIT








SCHEMATIC DIAGRAM - 3

A DVD MODULE CIRCUIT







SCHEMATIC DIAGRAM - 4

A DVD MODULE CIRCUIT


: CD HEAD SIGNAL LINE


: MOTOR DRIVE SIGNAL LINE

: +B SIGNAL LINE

: DVD HEAD SIGNAL LINE

: TRACKING ERROR SIGNAL LINE





B MAIN CIRCUIT



