



Buttons labelled such as ❶ function in exactly the same way as the buttons on the main unit.

Television operations



To mute the sound.

- Press the button to activate.
- Press the button again or adjust the volume to cancel.
- Muting is also canceled when you switch the unit to standby.



To dim the display panel.

Every time you press the button.

Setting	Effect
1	Display and ambient light dims
2	Display dims and ambient light is turned off
3	Original brightness

The display is dimmed, but brightens when you perform some operations.



This auto off function allows you to turn off the unit in disc or tape mode only after left unused for 10 minutes.

Every time you press the button:

SLEEP 30 → SLEEP 60 → SLEEP 90 → SLEEP 120
 SLEEP OFF ← **AUTO OFF** ←

- The setting is maintained even if the unit is turned off.
- If you select tuner or music port as the source, "AUTO OFF" turns off. It comes on again when you select disc or tape.