


5. Function & Operating Instruction

• 5-1 Product Dimension




MODEL	A	B	C	D	E	Remarks
SRG-L678EV	1750.0	994.5	1509.7	755	667	"X"
SRG-L676EV	1750.0	994.5	1509.7	755	667	"Y"
SR-L628EV	1750.0	994.5	1459.7	715	627	"X"
SR-L626EV	1750.0	994.5	1459.7	715	627	"Y"


5-2 Part Name & Disassembly

• Chilled Compartment disassembly

1. Pull it out by following the arrow.




2. Bend the cover and take it out.




• Top tray disassembly


Pull it forward.



Take out food stuffs and pull it out by following the arrow.





Take out the water bottle with the bottom latch pressed.




• Tray disassembly


Pull it out by following the arrow.



• Ice compartment



• Vegetable compartment



• Freezing compartment

