


Elenberg TV-807



19	KEY	1
18	SCREW PA2X6	5
17	SCREW KA2X6	20
16	LOGO	1
15	ANTENNA	1
14	MAIN PCB	1
13	HIGH voltage board	1
12	BACK CABINET	1
11	BACK IRON	1
10	BARACKET	6
9	BARACKET PIN	2
8	VGA	1
7	VGA PCB	1
6	PRESS BLOCK	1
5	8" LCD	1
4	KEY PCB	1
3	REMOTE LENS	1
2	SPEAKER	1
1	FRONT CABINET	1
NO. DESCRIPTION UNIT		

ITEM	SIGN	DATE	NAME	ITEM
DRAWER			TV807	SCALE
CHECKER				UNIT
ASSESSOR				
				 A4

Spare Parts List (TV-807)

[illegible]

