


















AV video





Scart_func1 → Scart_func1
Scart_func2 → Scart_func2
Main_BLK → Main_BLK

(11) VIDEO_S → VIDEO_S
(5,11) CVBS-TV → CVBS-TV


Scart signal







VIDEO_S → Scart_CLKOUT
CVBS-TV → Scart_DATA
Scart_func1 → Scart_SWITCH
Scart_func2 → RCA/Scart MCU












AV Audio



AV2



PC & YCrCb Audio



AV1_R_IN → AV1_R_IN (9)
AV1_L_IN → AV1_L_IN (9)
AV2_R_IN → AV2_R_IN (9)
AV2_L_IN → AV2_L_IN (9)
Y_R_IN → Y_R_IN (9)
Y_L_IN → Y_L_IN (9)
PC_R → PC_R (9)
PC_L → PC_L (9)

CVBS1 → CVBS1 (3.5)
CVBS2 → CVBS2 (3.5)

LUM1_IN → LUM1_IN (5)
CHR1_IN → CHR1_IN (5)

Y_IN → Y_IN (3.5)
Cb_IN → Cb_IN (3.5)
Cr_IN → Cr_IN (3.5)

Switch_BLK → Switch_BLK
L52 → L52
FB-7R → FB-7R

Switch_Y → Switch_Y
C609 → C609
R388 → R388
R391 → R391
NC → NC




Switch_Cr → Switch_Cr
C614 → C614
R394 → R394
R395 → R395
NC → NC

Switch_Cb → Switch_Cb
C615 → C615
R396 → R396
R397 → R397
NC → NC


APLUS

Connector Interface


File		Rev	3.2
Size	Document Number		
C	LM2030		
Date	Thursday, April 08, 2004	Sheet	6 of 14





EAR_L (10.11)
EAR_R (10.11)




APLUS			
Title			
AUDIO AMP.			
Size	Document Number		Rev
B	LM2030		3.2
Date:	Thursday, April 08, 2004	Sheet	8 of 14
		1	








Chip Interface





APLUS		
Title		
V-CHIP		
Size	Document Number	Rev
B	LM2030	3.2
Date: Thursday, April 08, 2004		
Sheet 14 of 14		