



LCD TV SERVICE GUIDE (V26)

■ Service guide


1) Black creen




2) White screen




3) Panel display abnormally




4) No sound




5) TV failure



6) **HDMI no picture or picture abnormal**



7) PC no picture or picture abnormal



8) YPBPR, AV, S-VIDEO, SCART no picture or picture abnormal

