




Block Diagram

TO CONTENTS





Schematic Diagram (2/9)



NOTE:#1:For CDA-9812RB Model Only,
\$1:For CDA-9812RR Model Only,
%1:For CDA-9811R Model Only,
Others:Common.

MAIN P.W. Board (2/4)
NOTE:N. U. is Not Used Parts.

TO P. W. Board

TO PARTS LIST

TO CONTENTS

1 |




3

4


MAIN P.W. Board (4/4)
NOTE: N. U. is Not Used Parts.

Schematic Diagram (5/9)
<CDA-9812RB Model Only>




FRONT P. W. Board
NOTE: N. U. is Not Used Parts.

Schematic Diagram (6/9)
<CDA-9812RR Model Only>



FRONT P.W. Board
NOTE: N. U. is Not Used Parts.


Schematic Diagram (7/9)
<CDA-9811R Model Only>



FRONT P.W. Board
NOTE: N. U. is Not Used Parts.

Schematic Diagram (8/9)

<CDA-9812RB/CDA-9812RR Model Only>




TO P. W. Board

TO PARTS LIST

TO CONTENTS

Schematic Diagram (9/9)
<CDA-9811R Model Only>



NOTE: N. U. is Not Used Parts.