


10. EXPLODED VIEW & PARTS LIST

1. Detachable Front Panel Section(TCC-5611)




(1) Assembly Parts

Ref.No.	Part No.	Description
A0	6762SE0028B	DETACHABLE FRONT ASS'Y
A01	3111SEM068B	FRONT CASE ASS'Y
A018	6871SE418AB	DETACHABLE FRONT PCB ASS'Y

(2) Individual Parts

Ref. No.	Part No.	Description
A003	5020S-0001A	"BUTTON, RELEASE"
A004	442-976E	"COIL, SPRING"
A007	5020S-0006A	"BUTTON, DECK FF"
A008	5020S-0007A	"BUTTON, DECK REW"
A010	5020S-0005A	"BUTTON, DECK EJECT"
A014	442-976J	"SPRING, FF/REW/EJECT"
A016	353-645A	"SCREW, SPECIAL 2X8 BK"
A017	3110S-M069A	REAR CASE

2. Main Section(TCC-5611)




(1) Assembly Parts

Ref. No.	Part No.	Description
AB01	3721SEM070C	TRIM PANEL ASS'Y
AB02	6871SE417AG	(FM/MW, LINE OUT)
	6871SE417AH	(FM/MW)
	6871SE417AJ	(FM/MW/LW)

(2) Individual Parts

Ref. No.	Part No.	Description
AB0202	6871SE422AB	TUNER PCB ASS 'Y(MW/LW)
	6871SE422AD	TUNER PCB ASS'Y(MW(AM))
AB0203	3110S-P035A	TERMINAL CASE
AB03	3140S-P017A	MAIN CHASSIS
AB04	4920S-D001D	HEAT SINK(DC 170 x 40)
AB05	1MBC0262018	SCREW(2.6 x 6)
AB06	3550S-0006A	"COVER, TOP"
AB07	3110S-P026A	"CASE, DIN SLEEVE"
AB08	1MRC0302818	ROUND HEAD MACHINE SCREW +
AB09	353-025G	SCREW(3 x 10)

3. Detachable Front Panel Section(TCC-5621)




(1) Assembly Parts

Ref.No.	Part No.	Description
A0	6762SE0029B	DETACHABLE FRONT ASS'Y
A01	3111SEM072B	FRONT CASE ASS'Y
A018	6871SE41DAB	DETACHABLE FRONT PCB ASS'Y

(2) Individual Parts

Ref. No.	Part No.	Description
A003	5020S-0016A	"BUTTON,RELEASE"
A004	442-976E	"COIL,SPRING"
A007	5020S-0019A	"BUTTON,DECK FF "
A008	5020S-0018A	"BUTTON,DECK REW "
A010	5020S-0017A	"BUTTON,EJECT "
A016	353-645A	SCREW(2X8)
A019	3110S-M069A	REAR CASE
A020	442-976J	SPRING, FF/REW/EJECT

4. Main Section(TCC-5621)




(1) Assembly Parts

Ref. No.	Part No.	Description
AB01	3721SEM071B	TRIM PANEL ASSY
AB02	6871SE417AG	(FM/MW, LINE OUT)
	6871SE417AH	(FM/MW)
	6871SE417AJ	(FM/MW/LW)

(2) Individual Parts

Ref. No.	Part No.	Description
AB0202	6871SE422AB	TUNER PCB ASS'Y(MW/LW)
	6871SE422AD	TUNER PCB ASS'Y(MW(AM)
AB0203	3110S-P035A	TERMINAL CASE
AB03	3140S-P017A	MAIN CHASSIS
AB04	4920S-D001D	HEAT SINK
AB05	1MBC0262018	SCREW(2.6 x 6)
AB06	3550S-0006A	"COVER,TOP"
AB07	3110S-P026A	"CASE,DIN SLEEVE"
AB08	1MRC0302818	SCREW (3 x 12)
AB09	353-025G	SCREW(3 x 10)

7. DECK SECTION



(1) Assembly Parts

Ref. No.	Part No.	Description
AC	6731SEK003A	DECK MECHANISM ASSY
AC05	6730S-K002A	DECK MECHANISM

(2) Individual Parts

Ref. No.	Part No.	Description
AC01	IMPC0301418	SCREW(M3 x 4)
AC02	4810S-1012A	BRACKET(DECK-REAR)
AC03	324-974B	"HOLDER, FF/REW"
AC04	4810S-1013A	BRACKET(DECK-REAR)
AC0501	6768S-OT01A	MOTOR ASSY TND EG5
AC0502	6768S-AT01A	ARM TND
AC0503	6768S-HT02A	HEAD TND MS35P-SF00
AC0504	6768S-AT01B	ARM TND
AC0505	6768S-TT01A	SWITCH TND QAS-1229
AC0506	6768S-TT01B	SWITCH TND SW-230-0
AC0507	6768S-BT01A	BELT/FELT TND
AC06	324-973B	EJECT HOLDER

