




MODEL: VITEK VT-3610 PARTS LIST

NO	DESCRIPTION	QTY	NO	DESCRIPTION	QTY	NO	DESCRIPTION	QTY
1	PANEL COVER	1	31	DIAL POINTER	1	61	WIRE CLAMPER	1
2	LENS FOR POINTER & AUTO STOP	1	32	TUNING COUPLER	1	62	HOUSING BRACKET	1
3	FRONT PANEL	1	33	TUNING SHAFT(WITH HX NUT)	1	63	ANT	1
4	BAL & TONE KNOB	1	34	BASE CABINET	1	64	LAMP HOLDER	2
5	TUNING REFLECTOR	1	35	TAPE DOOR	1	65	MOUNTING PLATE	1
6	TUNING GEAR	1	36	DRUM	1	66	M3 HEXAGON NUT	1
7	TUNING GEAR	1	37	LED HOLDER	1	67	BM 2.6X4 CHROMATE	2
8	BACK PANEL	1	38	LAMP CAP	4	68	FM 3/4 WHITE ZINC	3
9	TON GEAR	1	39	BAL/TON COUPLER	2	69	FM 3/5 WHITE ZINC	1
10	LOID BUTTON	1	40	SET CLAMPER	1	70	FM 3/6 WHITE ZINC	2
11	POWER BUTTON	1	41	POWER BOARD A'SSY	1	71	BTP 3/4 WHITE ZINC	2
12	MW/LW BUTTON	1	42	POWER BOARD A'SSY	1	72	BTP 3/4 WHITE ZINC	10
13	POWER BUTTON ADAPTOR	1	43	PULLY	4	73	KB 1.7X5 BLACK OXIDE	3
14	MW/LW BUTTON ADAPTOR	1	44	BRACKET RIGHT	1	74	KB 2/5.5 BLACK OXIDE	5
15	SPONGE	1	45	DECK BRACKET	1	75	KM 2/5.5 BLACK OXIDE	4
16	VOLUME BUTTON	1	46	PANEL LOCKER	1	76	KM 2/5.5 BLACK OXIDE	2
17	VOLUME REFLECTOR	1	47	LOCKER SPRING	1	77	PB 2/5.5 CHROMATE	2
18	VOLUME GEAR	1	48	WAF DOOR SPRING	1	78	PB 2/5.5 CHROMATE	2
19	AM/FM BUTTON	1	49	PCE HOLDER	1	79	PB 2/6 CHROMATE	7
20	LOID BUTTON ADAPTOR	1	50	VOLUME COUPLER	1	80	SPRING WASHER M2.6	2
21	AM/FM BUTTON ADAPTOR	1	51	SWITCH CAP	1	81	HM 5X1.5 CHROMATE	1
22	BAL & TONE KNOB	1	52	W/CH BOARD A'SSY	4	82	M5 HEXAGON NUT	2
23	BAL GEAR	1	53	LOD PLATE	1	83	SPRING WASHER M5	1
24	REL BUTTON	1	54	LOD HOLDER	1	84	PLAN WASHER M5	2
25	ELECT ARM CAP	1	55	ELECT ARM CAP	1	85	SPRING WASHER M4	1
26	STOP COVER	1	56	ELECT BRACKET	1	86	PB 4X1.2 CHROMATE	1
27	ELECT BUTTON SPRING	3	57	AUDIO REVERSE DECK A'SSY	1	87	DRUM SPRING	1
28	ELECT ARM CAP	1	58	TOP COVER LEFT	1	88	ROPE	1
29	ELECT ARM ADAPTOR	1	59	TOP COVER RIGHT	1			
30	PUSHER SPRING	1	60	BRACKET BACK	1			

